

Rescue platform

Assembly instructions

**AVV ARBEITSBÜHNEN
VERKAUF & VERMIETUNG**



Mit Sicherheit wäher drau!



1. Unlock the brakes of the swivel castors
2. Open the transport lock (fold down the bracket)



3. Pull apart the frame



4. Push up the cross and diagonal brace simultaneous until the latches snap



5. Insert the platform at the requested height



6. Release the safety clip, set the handrail to the requested height, push the safety clip in for locking



7. Block the swivel castor or check the base plate for secure stand



8. Adjust the rescue platform by height adjustment with quick lock, check the lock again



9. Attach the outriggers on the rescue platform



10. If necessary release the safety clip and adjust the telescopic feet of the outrigger to the requested height, push the safety clip in for locking



Warning!

No intermitted stress of the braces with latches.

